



ENVIRONMENTAL FACTORS

Practice:

At the onset of the design process, identify the operating conditions that will be encountered during the life of the equipment.

Benefits:

Each of the identified environmental factors requires consideration in the design process. This assures that adequate environmental strength is incorporated into the design to ensure reliability.

Programs That Certified Usage:

Space Electronic Rocket Test (SERT) I and II, Communication Technology Satellite (CTS), ACTS, Space Experiments, Launch Vehicles, Space Power Systems, and Space Station Freedom.

Center to Contact for More Information:

Lewis Research Center (LeRC)

Implementation Method:

To ensure a reliability-oriented design, determine the needed environmental resistance of the equipment. The initial requirement is to define the operating environment for the equipment. A Life-Cycle Environment Profile, containing this information, should be developed.

A Life-Cycle Environment Profile is a forecast of events and associated environmental conditions that an item experiences from manufacturing to retirement. The life cycle includes the phases that an item will encounter such as: handling, shipping, or storage prior to use; disposition between missions (storage, standby, or transfer to/from repair sites); geographical locations of expected deployment; and platform environments. The environment or combination of environments the equipment will encounter at each phase should be determined. All deployment scenarios should be described as a baseline to identify the environments most likely to be associated with each life cycle phase. The following factors should also be taken into account:

ENVIRONMENTAL FACTORS

- a. Hardware configuration.
- b. Environment(s) that will be encountered.
- c. Platform/hardware interfaces.
- d. Interfaces with other equipment.
- e. Absolute and relative duration of exposure phase.
- f. Probability that environmental condition(s) will occur.
- g. Geographical locations.
- h. Any other information that will help identify environmental conditions that may impact the item.

The steps in developing a Life-Cycle Environment Profile are as follows:

- 1) Describe anticipated events for an item of equipment, from final factory acceptance through terminal expenditure or removal from inventory.
- 2) Identify significant natural and induced environments or combination of environments for each anticipated shipping, storage, and logistic event (such as transportation, dormant storage, stand-by, bench handling, and ready modes, etc.).
- 3) Describe environmental and stress conditions (in narrative and statistical form) to which equipment will be subjected during the life cycle. Data may be derived by calculation, laboratory tests, or operational measurements. Estimated data should be replaced with actual values as determined. The profile should show the number of measurements used to obtain the average value of these stresses and design achievements as well as their variability (expressed as standard deviation).

ENVIRONMENTAL FACTORS

This analysis can be used to: develop environmental design criteria consistent with anticipated operating conditions, evaluate possible effects of change in environmental conditions, and provide traceability for the rationale applied in criteria selection for future use on the same program or other programs.

A listing of typical environmental factors is included in Table 1.

TABLE 1: ENVIRONMENTAL COVERAGE CHECKLIST (TYPICAL)

NATURAL	INDUCED
Albedo, Planetary IR	Acceleration
Clouds	Chemicals
Electromagnetic Radiation	Corona
Electrostatic Discharge	Electromagnetic, Laser
Fog	Electromagnetic Radiation
Freezing Rain	Electrostatic Discharge
Frost	Explosion
Fungus	Icing
Gravity, Low	Magnetics
Hail	Moisture
Humidity, High	Nuclear Radiation
Humidity, Low	Shock, Pyro, Thermal
Ice	Space Debris
Ionized Gases	Temperature, High, Aero. Heating, Fire
Lightning	Temperature, Low, Aero. Cooling
Magnetics, Geo	Turbulence
Meteoroids	Vapor Trails
Pollution, Air	Vibration, Mechanical, Microphonics
Pressure, High	Vibration, Acoustic
Pressure, Low, Vacuum	
Radiation, Cosmic, Solar	
Rain	
Salt Spray	
Sand and Dust	
Sleet	
Snow	
Temperature, High	
Temperature, Low	
Wind	

ENVIRONMENTAL FACTORS

Technical Rationale:

Given the dependence of equipment reliability on the operating conditions encountered during the life cycle, it is important that such conditions be identified accurately at the beginning of the design process. Environmental factors that strongly influence equipment reliability are included in Table 1, which provides a checklist for environmental coverage (typical).

Concurrent (combined) environments may be more detrimental to reliability than the effects of a single environment. In characterizing the design process, design/test criteria must consider both single and/or combined environments in anticipation of providing the hardware capability to withstand the hazards identified in the system profile. The effects of typical combined environments are illustrated in a matrix relationship in Figure 1, which shows combinations where the total effect is more damaging than the cumulative effect of each environment acting independently. For example, an item may be exposed to a combination such as temperature, humidity, altitude, shock, and vibration while it is being transported. The acceptance to end-of-life history of an item must be examined for these effects. Table 2 provides reliability considerations for pairs of environmental factors.

Each environmental factor that is present requires a determination of its impact on the operational and reliability characteristics of the materials and parts comprising the equipment being designed. Packaging techniques should be identified that afford the necessary protection against the degrading factors.

In the environmental stress identification process that precedes selection of environmental strength techniques, it is essential to consider stresses associated with all life intervals of the equipment. This includes operational and maintenance environments as well as the pre-operational environments, when stresses imposed on the parts during manufacturing assembly, inspection, testing, shipping, and installation may have significant impact on equipment reliability. Stresses imposed during the pre-operational phase often are overlooked; however, they may represent a particularly harsh environment that the equipment must withstand. Often, the environments to which systems are exposed during shipping and installation are more severe than those encountered during normal operating conditions. It is probable that some of the environmental strength features that are contained in a system design pertain to conditions that will be encountered in the pre-operational phase rather than during actual operation.

ENVIRONMENTAL FACTORS

TABLE 2: VARIOUS ENVIRONMENTAL PAIRS

High Temperature And Humidity	High Temperature And Low Pressure	High Temperature And Salt Spay
<p>High temperature tends to increase the rate of moisture penetration. The general deterioration effects of humidity are increased by high temperatures.</p>	<p>Each of these environments depends on the other. For example, as pressure decreases, outgassing of constituents of materials increases; as temperature increases, outgassing increases. Hence, each tends to intensify the effects of the other.</p>	<p>High temperature tends to increase the rate of corrosion caused by salt spray.</p>
High Temperature and Solar Radiation	High Temperature and Fungus	High Temperature and Sand and Dust
<p>This is a man-independent combination that causes increasing effects on organic materials.</p>	<p>A certain degree of high temperature is necessary to permit fungus and microorganisms to grow. However, fungus and microorganisms cannot develop above 160°F (71°C).</p>	<p>The erosion rate of sand may be accelerated by high temperature. However, high temperature reduces sand and dust penetration.</p>
High Temperature and Shock and Vibration	High Temperature and Acceleration	High Temperature and Explosive Atmosphere
<p>Since both environments affect common material properties, they will intensify each other's effects. The degree to which the effects are intensified depends on the magnitude of each environment in the combination. Plastics and polymers are more susceptible to this combination than metals, unless extremely high temperatures are involved.</p>	<p>This combination produces the same effect as high temperature and shock and vibration.</p>	<p>Temperature has minimal effect on the ignition of an explosive atmosphere but does affect the air-vapor ratio, which is an important consideration.</p>

ENVIRONMENTAL FACTORS

TABLE 2: VARIOUS ENVIRONMENTAL PAIRS

Low Temperature and Humidity	High Temperature and Ozone	
Relative humidity increases as temperature decreases, and lower temperature may induce moisture condensation. If the temperature is low enough, frost or ice may result.	Starting at about 300°F (150°C) temperature starts to reduce ozone. Above about 520°F (270°C), ozone cannot exist at pressures normally encountered.	
Low Temperature and Solar Radiation	Low Temperature and Low Pressure	Low Temperature and Salt Spray
Low temperature tends to reduce the effects of solar radiation and vice versa.	This combination can accelerate leakage through seals, etc.	Low temperature reduces the corrosion rate of salt spray.
	Low Temperature and Sand and Dust	Low Temperature and Fungus
	Low temperature increases dust penetration.	Low temperature reduces fungus growth. At sub-zero temperatures, fungi remain in suspended animation.
Low Temperature and Shock and Vibration	Low Temperature and Acceleration	Low Temperature and Explosive Atmosphere
Low temperature tends to intensify the effects of shock and vibration. However, it is a consideration only at very low temperatures.	This combination produces the same effect as low temperature and shock and vibration.	Temperature has minimal effect on the ignition of an explosive atmosphere but does affect the air-vapor ratio, which is an important consideration.
Low Temperature and Ozone	Humidity and Low Pressure	Humidity and Salt Spray
Ozone effects are reduced at lower temperatures but ozone concentration increases with lower temperatures.	Humidity increases the effects of low pressure, particularly in relation to electronic or electrical equipment. However, the actual effectiveness of this combination is determined primarily by the temperature.	High humidity may dilute the salt concentration and could affect the corrosive action of the salt by increasing the coverage, thereby increasing the conductivity.
Humidity and Fungus	Humidity and Sand and Dust	Humidity and Solar Radiation
Humidity helps the growth of fungus and microorganisms but adds nothing to their effects.	Sand and dust have a natural affinity for water and this combination increases deterioration.	Humidity intensifies the deteriorating effects of solar radiation on organic materials.

ENVIRONMENTAL FACTORS

TABLE 2: VARIOUS ENVIRONMENTAL PAIRS

Humidity and Vibration	Humidity and Shock and Acceleration	Humidity and Explosive Atmosphere
This combination tends to increase the rate of breakdown of electrical material.	The periods of shock and acceleration are considered too short for these environments to be affected by humidity.	Humidity has no effect on the ignition of an explosive atmosphere but a high humidity will reduce the pressure of an explosion.
Humidity and Ozone	Low Pressure and Salt Spray	Low Pressure and Solar Radiation
Ozone meets with moisture to form hydrogen peroxide, which has a greater deteriorating effect on plastics and elastomers than the additive effects of moisture and ozone.	This combination is not expected to occur.	This combination does not add to the overall effects.
	Low Pressure and Fungus	
	This combination does not add to the overall effects.	
Low Pressure and Sand and Dust	Low Pressure and Vibration	Low Pressure and Shock or Acceleration
This combination only occurs in extreme storms during which small dust particles are carried to high altitudes.	This combination intensifies effects in all equipment categories but mostly with electronic and electrical equipment.	These combinations only become important at the hyperenvironmental levels, in combination with high temperature.
Low Pressure and Explosive Atmosphere	Salt Spray and Fungus	Salt Spray and Dust
At low pressures, an electrical discharge is easier to develop but the explosive atmosphere is harder to ignite.	This is considered an incompatible combination.	This will have the same combined effect as humidity and sand and dust.

ENVIRONMENTAL FACTORS

TABLE 2: VARIOUS ENVIRONMENTAL PAIRS

Salt Spray and Vibration	Salt Spray and Shock or Acceleration	Salt Spray and Explosive Atmosphere
This will have the same combined effect as humidity and vibration.	These combinations produce no added effects.	This is considered an incompatible combination.
Salt Spray and Ozone	Solar Radiation and Fungus	Solar Radiation and Sand and Dust
This combination is similar to but more corrosive than humidity and ozone.	Because of the resulting heat from solar radiation, this combination probably produces the same combined effect as high temperature and fungus. Further, the ultraviolet in unfiltered radiation is an effective fungicide.	It is suspected that this combination will produce high temperatures.
Solar Radiation and Ozone	Fungus and Ozone	Solar Radiation and Shock or Acceleration
This combination increases the rate of oxidation of materials.	Fungus is destroyed by ozone.	These combinations produce no added effects.
Solar Radiation and Vibration		Sand and Dust and Vibration
Under vibration conditions, solar radiation deteriorates plastics, elastomers, oils, etc., at a higher rate.		Vibration might possibly increase the wearing effects of sand and dust.
Shock and Vibration	Vibration and Acceleration	
This combination produces no added effects.	This combination produces increased effects when encountered with high temperatures and low pressure in the hyperenvironmental ranges.	
Solar Radiation and Explosive Atmosphere		
This combination produces no added effects.		

ENVIRONMENTAL FACTORS

Environmental stresses affect parts in different ways. Table 3 illustrates the principal effects of typical environments on system parts and materials.

High temperatures impose a severe stress on most electronic items, since it can cause catastrophic failure (such as melting of solder joints and burnout of solid-state devices). High temperature also causes progressive deterioration of reliability due primarily to chemical degradation effects.¹ It is often stated that excessive temperature is the primary cause of poor reliability in electronic equipment.

In electronic systems design, great emphasis is placed on small size and high part densities. This generally requires a cooling system to provide a path of low thermal resistance from heat-producing elements to an ultimate heat sink of reasonably low temperature.

Solid-state parts are rated in terms of maximum junction temperatures. The thermal resistance is usually specified from this point to either case or to free air. Specification of the maximum ambient temperature for which a part is suitable generally is not a sufficient method for part selection, since the surface temperature of a particular part can be greatly influenced by heat radiation or heat conduction effects from nearby parts. These effects can lead to overheating, even though an ambient temperature rating appears not to be exceeded. It is preferable to specify thermal environment ratings such as equipment surface temperatures, thermal resistance paths associated with conduction, convection, and radiation effects, and cooling provisions such as air temperature, pressure, and velocity. In this manner, the true thermal state of the internal components of temperature-sensitive components can be determined. Reliability improvement techniques for high temperature stress include the use of heat dissipation devices, cooling systems, thermal insulation, and heat-withstanding materials.

Low temperatures experienced by electronic equipment can cause reliability problems. These problems usually are associated with mechanical system elements. They include mechanical stresses produced by differences in the coefficients of expansion (contraction) of metallic and nonmetallic materials, embrittlement of nonmetallic components, mechanical forces caused by freezing of entrapped moisture, stiffening of liquid constituents, etc. Typical examples include cracking of seams, binding of mechanical linkages, and excessive viscosity of lubricants. Reliability improvement techniques for low temperature stress include the use of heating devices, thermal insulation, and cold-withstanding materials.

¹See Practice No. PT-TE-1404, "Thermal Test Levels/Durations."

ENVIRONMENTAL FACTORS

TABLE 3: ENVIRONMENTAL EFFECTS

ENVIRONMENT	PRINCIPAL EFFECTS	TYPICAL FAILURES INDUCED
High temperature	Thermal aging: Oxidation Structural change Chemical reaction Softening, melting, and sublimation Viscosity reduction/evaporation Physical expansion	Insulation failure Alteration of electrical properties. Structural failure. Loss of lubrication properties. Structural failure; increased mechanical stress; increased wear on moving parts.
Low temperature	Increased viscosity and solidification Ice formation Embrittlement Physical contraction	Loss of lubrication properties. Alteration of electrical properties. Loss of mechanical strength; cracking, fracture. Structural failure; increased wear on moving parts.
High relative humidity	Moisture absorption Chemical reaction Corrosion Electrolysis	Swelling, rupture of container; Physical breakdown; Loss of electrical strength; Loss of mechanical strength; Interference with function; Loss of electrical properties; Increased conductivity of insulators.
Low relative humidity	Desiccation Embrittlement Granulation	Loss of mechanical strength; Structural collapse; Alteration of electrical properties, "dusting".
High pressure	Compression	Structural collapse; Penetration of sealing; Interference with function.

ENVIRONMENTAL FACTORS

TABLE 3: ENVIRONMENTAL EFFECTS

Low pressure	Expansion Outgassing Reduced dielectrical strength of air	Fracture of container; Explosive expansion. Alteration of electrical properties; Loss of mechanical strength. Insulation breakdown and arc-over; Corona and ozone formation.
Solar radiation	Actinic and physicochemical reactions: Embrittlement	Surface deterioration; Alteration of electrical properties; Discoloration of materials; Ozone formation.
Sand and dust	Abrasion Clogging	Increased wear. Interference with function; Alteration of electrical properties.
Salt spray	Chemical reactions: Corrosion Electrolysis	Increased wear. Loss of mechanical strength; Alteration of electrical properties; Interference with function. Surface deterioration; Structural weakening; Increased conductivity.
Wind	Force application Deposition of materials Heat loss (low velocity) Heat gain (high velocity)	Structural collapse; Interference with function Loss of mechanical strength. Mechanical Interference and clogging; Abrasion accelerated. Accelerates low-temperature effects. Accelerates high-temperature effects.

ENVIRONMENTAL FACTORS

TABLE 3: ENVIRONMENTAL EFFECTS

Rain	Physical Stress Water absorption and immersion	Structural collapse. Increase in weight; Electrical failure; Structural weakening.
	Erosion	Removes protective coatings; Structural weakening; Surface deterioration.
	Corrosion	Enhances chemical reactions.
Temperature shock	Mechanical stress	Structural collapse or weakening; Seal damage.
High-speed particles (nuclear irradiation)	Heating Transmutation and ionization	Thermal aging; Oxidation. Alteration of chemical, physical, and electrical properties; Production of gases and secondary particles.
Zero gravity	Mechanical stress Absence of convection cooling	Interruption of gravity-dependent functions. Aggravation of high-temperature effects.
Ozone	Chemical reactions: Crazing, cracking Embrittlement Granulation Reduced dielectrical strength of air	Rapid oxidation; Alteration of electrical properties; Loss of mechanical strength; Interference with function. Insulation breakdown and arc-over.
Explosive decompression	Severe mechanical stress	Rupture and cracking; Structural collapse.
Dissociated gases	Chemical reactions: Contamination Reduced dielectric strength	Alteration of physical and electrical properties. Insulation breakdown and arc-over.
Acceleration	Mechanical stress	Structural collapse.

ENVIRONMENTAL FACTORS

TABLE 3: ENVIRONMENTAL EFFECTS

Vibration	Mechanical Stress Fatigue	Loss of mechanical strength; Interference with function; Increased wear. Structural collapse.
Magnetic fields	Induced magnetization	Interference with function; Alteration of electrical properties; Induced heating.

Additional stresses are produced when electronic equipment is exposed to sudden changes of temperature or rapidly changing thermal cycling conditions. These conditions generate large internal mechanical stresses in structural elements, particularly when dissimilar materials are involved. Effects of thermal shock-induced stresses include cracking of seams, delamination, loss of hermeticity, leakage of fill gases, separation of encapsulating materials from components and enclosure surface leading to the creation of voids, and distortion of support members.

A thermal shock test may be specified to determine the integrity of solder joints since such a test creates large internal forces due to differential expansion effects. Such a test also has been found to be instrumental in creating segregation effects in solder alloys leading to the formation of lead-rich zones, which are susceptible to cracking effects.

Electronic equipment often is subjected to environmental shock and vibration during both normal use and testing. Such environments can cause physical damage to parts and structural members when deflections produced cause mechanical stresses which exceed the allowable working stress of the constituent parts.

Natural frequencies of items comprising the equipment are important parameters that must be considered in the design process since a resonant condition can be produced if a natural frequency is within the vibration frequency range. The resonance condition will greatly amplify subsystem deflection and may increase stresses beyond the safe limit.

The vibration environment can be particularly severe for electrical connectors, since it may cause relative motion between members of the connector. In combination with other environmental stresses, this motion can produce fret corrosion. This generates wear debris and causes large variation in contact resistance. Reliability improvement techniques for vibrational stress include the use of stiffening, control of resonance, and reduced freedom of movement.

ENVIRONMENTAL FACTORS

Humidity and salt air environments can cause degradation of equipment performance since they promote corrosion effects in metallic components. They also can foster the creation of galvanic cells, particularly when dissimilar metals are in contact. Another deleterious effect of humidity and salt air atmosphere is the formation of surface films on nonmetallic parts. These films cause leakage paths and degrade the insulation and dielectric properties of these materials. Moisture absorption by insulating materials also can cause a significant increase in volume conductivity and the dissipation factor of these materials. Reliability improvement techniques for humidity and salt environments include use of hermetic sealing, moisture-resistant material, dehumidifiers, protective coatings/covers, and reduced use of dissimilar metals.

Electromagnetic and nuclear radiation can disrupt performance levels and, in some cases, cause permanent damage to exposed equipment. Therefore, it is important that such effects be considered in determining the environmental strength for electronic equipment that must achieve a specified reliability goal.

Electromagnetic radiation often produces interference and noise effects within electronic circuitry, which can impair system performance. Sources of these effects include corona or lightning discharges, sparking, and arcing phenomena. These may be associated with high voltage transmission lines, ignition systems, brush type motors, and even the equipment itself. Generally, the reduction of interference effects requires incorporating filtering and shielding features or specifying less susceptible components and circuitry.

Nuclear radiation can cause permanent damage by alteration of the atomic or molecular structure of dielectric and semiconductor materials. High energy radiation also can cause ionization effects that degrade the insulation levels of dielectric materials. The migration of nuclear radiation effects typically involves materials and parts possessing a higher degree of radiation resistance, and the incorporation of shielding and hardening techniques.

Each environmental factor experienced by an item during its life cycle requires consideration in the design process. This ensures that adequate environmental strength is incorporated into the design for reliability.

Impact of Nonpractice:

Failure to perform a detailed life cycle environment profile can lead to overlooking environmental factors whose effect is critical to equipment reliability. If these factors are not included in the environmental design criteria and test program, environment-induced failures may occur during space flight operations.

ENVIRONMENTAL FACTORS

References:

Government

1. MIL-HDBK-217E Notice 1, "Reliability Prediction of Electronic Equipment," January 1990.
2. MIL-HDBK-251, "Reliability/Design Thermal Applications," January 1978.
3. MIL-HDBK-338-1A, "Electronic Reliability Design Handbook," October 1988.
4. MIL-STD-810E, "Environmental Test Methods and Engineering Guidelines," July 1989.

Industry

5. EID-00866, Rocketdyne Division, Rockwell International, "Space Station Freedom Electric Power System Reliability and Maintainability Guidelines Document," 1990.
6. SAE G-11, Society of Automotive Engineers, Reliability, Maintainability, and Supportability Guidebook, 1990.